


§ Wide Angle *METER* § L Series
SYNCHROSCOPE METER (TRANSDUCER TYPE) DL

1. SYNCHROSCOPE METER

Method	Type	Rated Voltage	Rated Frequency	Approx. Consumption VA	
				Start side	Bus side
Single phase	DL-110ND-12	110V	Serve 50Hz & 60Hz	0.2VA	4.0VA
3-phase	DL-110ND-33	110V	Serve 50Hz & 60Hz	0.4VA each phase	4.0VA
		220V	Serve 50Hz & 60Hz	0.4VA each phase	4.0VA

► In the case of rating exceeding those above, use an 110V meter together with an external CT.

CONNECTION DIAGRAM



DIMENSIONS

Single phase DL-110ND-12 3-phase DL-110ND-33

